



IST

FLC[®]
Fast Lamp Change

Fast Lamp Change FLC®

Features:

- **Lamp changes in a few seconds**

It is now possible to change UV lamps in a matter of seconds as they can be removed from the housing in a few simple steps.

- **No special tools needed**

As there are no parts to unscrew or cables to disconnect the UV lamps can be changed at any time by a trained operator.

- **Doped lamps available**

The full range of IST doped lamps is available in the FLC® lamp range.

- **Trouble free fitting in existing systems**

As the dimensions of the new FLC® lamps are identical to those of standard IST lamps it is no problem to switch to the FLC® system.



Fast Lamp Change FLC®

Quick and easy lamp changes with the FLC® system



- **Removal of the UV lamp**
The lamp is easily lifted out of the housing and removed from the unit using the tool supplied.

No additional tools are necessary, as there are no screws to remove or cables to disconnect.

- **Inserting the new lamp**
The new lamp is simply placed in the lamp housing. The lamp locks into place automatically when lightly pressed into the lamp socket.

The lamp unit is now ready for use and can be inserted back into the machine.